

Year	System	Sys. Info.	Read-Clear Dtc	Data Stream	Freeze Data	Actuation	Special Functions	Others
<b>ACCORD</b>								
up to 1998	ENGINE		<i>err. code</i>	<i>data</i>	<i>Freeze</i>	<i>Actuat.</i>		
	SRS		<i>err. code</i>	<i>data</i>				
1999-2003	ENGINE		<i>err. code</i>	<i>data</i>	<i>Freeze</i>	<i>Actuat.</i>		
	AT		<i>err. code</i>	<i>data</i>	<i>Freeze</i>	<i>Actuat.</i>		
	ABS		<i>err. code</i>	<i>data</i>	<i>Freeze</i>	<i>Actuat.</i>		
	SRS		<i>err. code</i>	<i>data</i>				
	EPS		<i>err. code</i>	<i>data</i>	<i>Freeze</i>			
From 2004	ENGINE		<i>err. code</i>	<i>data</i>	<i>Freeze</i>	<i>Actuat.</i>	1.Adjustment(*)	
	AT		<i>err. code</i>	<i>data</i>	<i>Freeze</i>	<i>Actuat.</i>		
	ABS		<i>err. code</i>	<i>data</i>	<i>Freeze</i>	<i>Actuat.</i>		
	SRS		<i>err. code</i>	<i>data</i>		<i>Actuat.</i>	1.Adjustment(*)	
	OPDS		<i>err. code</i>				1.Adjustment(*)	
	SWS		<i>err. code</i>				1.Check(*) 2.Adjustment(*)	
	BCM		<i>err. code</i>	<i>data</i>		<i>Actuat.</i>	1.Adjustment(*)	
	IMA(HYBRID)		<i>err. code</i>	<i>data</i>	<i>Freeze</i>	<i>Actuat.</i>		
	Keyless Access System		<i>err. code</i>	<i>data</i>		<i>Actuat.</i>		1.Keys Function(*) 2. Replace HONDA SMART KEY ECU 3. Replace KNOB Ignition
	IMMOBILIZER	<i>info</i>						1.Keys Function(*) 2.Replace IMM Unit (*) 3. Replace ECM/PCM(*) 4. Replace MPCS/MIC U/IMOES(*)
<b>ACTY</b>								
1992-2003	ENGINE		<i>err. code</i>	<i>data</i>	<i>Freeze</i>	<i>Actuat.</i>		
	SRS		<i>err. code</i>	<i>data</i>				
	ENGINE		<i>err. code</i>	<i>data</i>	<i>Freeze</i>	<i>Actuat.</i>		

From 2004	ABS		<i>err. code</i>	<i>data</i>	<i>Freeze</i>	<i>Actuat.</i>		
	SRS		<i>err. code</i>	<i>data</i>		<i>Actuat.</i>		
	IMMOBILIZER	<i>info</i>						1.Keys Function(*)

### ACURA EL

From 1999	ENGINE		<i>err. code</i>	<i>data</i>		<i>Actuat.</i>		
	AT		<i>err. code</i>	<i>data</i>		<i>Actuat.</i>		
	ABS		<i>err. code</i>	<i>data</i>		<i>Actuat.</i>		
	SRS		<i>err. code</i>	<i>data</i>				
	IMMOBILIZER	<i>info</i>						1.Keys Function(*)

### ACURA CL

From 1999	ENGINE		<i>err. code</i>	<i>data</i>	<i>Freeze</i>	<i>Actuat.</i>		
	AT		<i>err. code</i>	<i>data</i>	<i>Freeze</i>	<i>Actuat.</i>		
	ABS		<i>err. code</i>	<i>data</i>	<i>Freeze</i>	<i>Actuat.</i>		
	SRS		<i>err. code</i>	<i>data</i>				
	IMMOBILIZER	<i>info</i>						1.Keys Function(*) 2.Replace IMM Unit (*) 3. Replace ECM/PCM(*) 4. Replace MPCS/MIC U/IMOES(*)

### ACURA CSX

	ENGINE		<i>err. code</i>	<i>data</i>	<i>Freeze</i>	<i>Actuat.</i>		
	AT		<i>err. code</i>	<i>data</i>	<i>Freeze</i>	<i>Actuat.</i>		
	ABS		<i>err. code</i>	<i>data</i>	<i>Freeze</i>	<i>Actuat.</i>		

From 1999	SRS		<i>err. code</i>	<i>data</i>				
	IMMOBILIZER	<i>info</i>						1.Keys Function(*) 2.Replace IMM Unit (*) 3. Replace ECM/PCM(*) 4. Replace MPCS/MIC U/IMOES(*)

## ACURA MDX

From 1999	ENGINE		<i>err. code</i>	<i>data</i>	Freeze	<i>Actuat.</i>		
	AT		<i>err. code</i>	<i>data</i>	Freeze	<i>Actuat.</i>		
	ABS		<i>err. code</i>	<i>data</i>	Freeze	<i>Actuat.</i>		
	SRS		<i>err. code</i>	<i>data</i>				
	VTM-4		<i>err. code</i>	<i>data</i>	Freeze	<i>Actuat.</i>		
	SH-AWD		<i>err. code</i>	<i>data</i>	Freeze	<i>Actuat.</i>	1.Adjustment(*)	
	IMMOBILIZER	<i>info</i>						1.Keys Function(*) 2.Replace IMM Unit (*) 3. Replace ECM/PCM(*) 4. Replace MPCS/MIC U/IMOES(*)

## ACURA RDX

From 1999	ENGINE		<i>err. code</i>	<i>data</i>	Freeze	<i>Actuat.</i>		
	AT		<i>err. code</i>	<i>data</i>	Freeze	<i>Actuat.</i>		
	ABS		<i>err. code</i>	<i>data</i>	Freeze	<i>Actuat.</i>		

	SRS		<i>err. code</i>	<i>data</i>				
	IMMOBILIZER	<i>info</i>						1.Keys Function(*)

### ACURA RSX

From 1999	ENGINE		<i>err. code</i>	<i>data</i>	<i>Freeze</i>	<i>Actuat.</i>		
	AT		<i>err. code</i>	<i>data</i>	<i>Freeze</i>	<i>Actuat.</i>		
	ABS		<i>err. code</i>	<i>data</i>	<i>Freeze</i>	<i>Actuat.</i>		
	SRS		<i>err. code</i>	<i>data</i>				
	IMMOBILIZER	<i>info</i>						1.Keys Function(*)

### ACURA TSX

From 1999	ENGINE		<i>err. code</i>	<i>data</i>	<i>Freeze</i>	<i>Actuat.</i>		
	AT		<i>err. code</i>	<i>data</i>	<i>Freeze</i>	<i>Actuat.</i>		
	ABS		<i>err. code</i>	<i>data</i>	<i>Freeze</i>	<i>Actuat.</i>		
	SRS		<i>err. code</i>	<i>data</i>				
	IMMOBILIZER	<i>info</i>						1.Keys Function(*) 2.Replace IMM Unit (*) 3. Replace ECM/PCM(*) 4. Replace MPCS/MIC U/IMOES(*)

### AIRWAVE

	ENGINE		<i>err. code</i>	<i>data</i>	<i>Freeze</i>	<i>Actuat.</i>		
	AT		<i>err. code</i>	<i>data</i>	<i>Freeze</i>	<i>Actuat.</i>		
	ABS		<i>err. code</i>	<i>data</i>	<i>Freeze</i>	<i>Actuat.</i>		
	SRS		<i>err. code</i>	<i>data</i>				

From 1999	EPS		<i>err. code</i>	<i>data</i>	<i>Freeze</i>	<i>Actuat.</i>		
	IMMOBILIZER	<i>info</i>						1.Keys Function(*) 2.Replace IMM Unit (*) 3. Replace ECM/PCM(*) 4. Replace MPCS/MIC U/IMOES(*)

### ASCOT

From 1999	ENGINE		<i>err. code</i>	<i>data</i>	<i>Freeze</i>	<i>Actuat.</i>		
	SRS		<i>err. code</i>	<i>data</i>				

### AVANCIER

From 1999	ENGINE		<i>err. code</i>	<i>data</i>	<i>Freeze</i>	<i>Actuat.</i>		
	AT		<i>err. code</i>	<i>data</i>	<i>Freeze</i>	<i>Actuat.</i>		
	ABS		<i>err. code</i>	<i>data</i>	<i>Freeze</i>	<i>Actuat.</i>		
	SRS		<i>err. code</i>	<i>data</i>				
	IMMOBILIZER	<i>info</i>						1.Keys Function(*) 2.Replace IMM Unit (*) 3. Replace ECM/PCM(*) 4. Replace MPCS/MIC U/IMOES(*)

### CAPA

From 1999	ENGINE		<i>err. code</i>	<i>data</i>	<i>Freeze</i>	<i>Actuat.</i>		
	AT		<i>err. code</i>	<i>data</i>	<i>Freeze</i>	<i>Actuat.</i>		
	ABS		<i>err. code</i>	<i>data</i>	<i>Freeze</i>	<i>Actuat.</i>		
	SRS		<i>err. code</i>	<i>data</i>				

	IMMOBILIZER	<i>info</i>						1.Keys Function(*)
--	-------------	-------------	--	--	--	--	--	-----------------------

## CITY

From 1999	ENGINE		<i>err. code</i>	<i>data</i>	<i>Freeze</i>	<i>Actuat.</i>		
	AT		<i>err. code</i>	<i>data</i>	<i>Freeze</i>	<i>Actuat.</i>		
	ABS		<i>err. code</i>	<i>data</i>	<i>Freeze</i>	<i>Actuat.</i>		
	SRS		<i>err. code</i>	<i>data</i>				
	EPS		<i>err. code</i>	<i>data</i>	<i>Freeze</i>	<i>Actuat.</i>		
	IMMOBILIZER	<i>info</i>						1.Keys Function(*) 2.Replace IMM Unit (*) 3. Replace ECM/PCM(*) 4. Replace MPCS/MIC U/IMOES(*)

## CIVIC

Up to 2004	ENGINE		<i>err. code</i>	<i>data</i>	<i>Freeze</i>	<i>Actuat.</i>		
	AT		<i>err. code</i>	<i>data</i>	<i>Freeze</i>	<i>Actuat.</i>		
	ABS		<i>err. code</i>	<i>data</i>	<i>Freeze</i>	<i>Actuat.</i>		
	SRS		<i>err. code</i>	<i>data</i>				
	EPS		<i>err. code</i>	<i>data</i>	<i>Freeze</i>	<i>Actuat.</i>		
	IMA(HYBRID)		<i>err. code</i>	<i>data</i>	<i>Freeze</i>	<i>Actuat.</i>		

	IMMOBILIZER	<i>info</i>						1.Keys Function(*) 2.Replace IMM Unit (*) 3. Replace ECM/PCM(*) 4. Replace MPCS/MIC U/IMOES(*)
From 2005	ENGINE		<i>err. code</i>	<i>data</i>	<i>Freeze</i>	<i>Actuat.</i>		
	AT		<i>err. code</i>	<i>data</i>	<i>Freeze</i>	<i>Actuat.</i>		
	ABS		<i>err. code</i>	<i>data</i>	<i>Freeze</i>	<i>Actuat.</i>		
	SRS		<i>err. code</i>	<i>data</i>				
	OPDS		<i>err. code</i>	<i>data</i>			1.Adjustment(*)	
	EPS		<i>err. code</i>	<i>data</i>	<i>Freeze</i>	<i>Actuat.</i>		
	BCM		<i>err. code</i>	<i>data</i>		<i>Actuat.</i>	1.Check(*) 2.Adjustment(*)	
	IMMOBILIZER	<i>info</i>						1.Keys Function(*) 2.Replace IMM Unit (*) 3. Replace ECM/PCM(*) 4. Replace MPCS/MIC U/IMOES(*)
	IMA(HYBRID)		<i>err. code</i>	<i>data</i>	<i>Freeze</i>	<i>Actuat.</i>		
	HYDRBST		<i>err. code</i>	<i>data</i>		<i>Actuat.</i>	1.Adjustment(*)	
i-SHIFT		<i>err. code</i>	<i>data</i>					

**CR-V**

Up to 2003	ENGINE		<i>err. code</i>	<i>data</i>	<i>Freeze</i>	<i>Actuat.</i>		
	AT		<i>err. code</i>	<i>data</i>	<i>Freeze</i>	<i>Actuat.</i>		
	ABS		<i>err. code</i>	<i>data</i>	<i>Freeze</i>	<i>Actuat.</i>		
	SRS		<i>err. code</i>	<i>data</i>				
From 2004	ENGINE		<i>err. code</i>	<i>data</i>	<i>Freeze</i>	<i>Actuat.</i>		
	AT		<i>err. code</i>	<i>data</i>	<i>Freeze</i>	<i>Actuat.</i>		
	ABS		<i>err. code</i>	<i>data</i>	<i>Freeze</i>	<i>Actuat.</i>		
	SRS		<i>err. code</i>	<i>data</i>				
	OPDS		<i>err. code</i>	<i>data</i>			1.Adjustment(*)	
	BCM		<i>err. code</i>	<i>data</i>		<i>Actuat.</i>	1.Check(*) 2.Adjustment(*)	
	IMMOBILIZER	<i>info</i>						1.Keys Function(*) 2.Replace IMM Unit (*) 3. Replace ECM/PCM(*) 4. Replace MPCS/MIC U/IMOES(*)
<b>CR-X/delsol</b>								
	ENGINE		<i>err. code</i>	<i>data</i>	<i>Freeze</i>	<i>Actuat.</i>		
	AT		<i>err. code</i>	<i>data</i>	<i>Freeze</i>	<i>Actuat.</i>		
	ABS		<i>err. code</i>	<i>data</i>	<i>Freeze</i>	<i>Actuat.</i>		
	SRS		<i>err. code</i>	<i>data</i>				



From 1999	IMMOBILIZER	<i>info</i>							1.Keys Function(*) 2.Replace IMM Unit (*) 3. Replace ECM/PCM(*) 4. Replace MPCS/MIC U/IMOES(*)
-----------	-------------	-------------	--	--	--	--	--	--	--

### CROSSRO AD

From 1999	ENGINE		<i>err. code</i>	<i>data</i>	<i>Freeze</i>	<i>Actuat.</i>		
	AT		<i>err. code</i>	<i>data</i>	<i>Freeze</i>	<i>Actuat.</i>		
	ABS		<i>err. code</i>	<i>data</i>	<i>Freeze</i>	<i>Actuat.</i>		
	SRS		<i>err. code</i>	<i>data</i>				
	EPS		<i>err. code</i>	<i>data</i>	<i>Freeze</i>	<i>Actuat.</i>		
	IMMOBILIZER	<i>info</i>						

### DOMANI

	ENGINE		<i>err. code</i>	<i>data</i>	<i>Freeze</i>	<i>Actuat.</i>		
	AT		<i>err. code</i>	<i>data</i>	<i>Freeze</i>	<i>Actuat.</i>		
	ABS		<i>err. code</i>	<i>data</i>	<i>Freeze</i>	<i>Actuat.</i>		
	SRS		<i>err. code</i>	<i>data</i>				

From 1999	IMMOBILIZER	<i>info</i>							1.Keys Function(*) 2.Replace IMM Unit (*) 3. Replace ECM/PCM(*) 4. Replace MPCS/MIC U/IMOES(*)
-----------	-------------	-------------	--	--	--	--	--	--	--

## EDIX

From 1999	ENGINE		<i>err. code</i>	<i>data</i>	<i>Freeze</i>	<i>Actuat.</i>			
	AT		<i>err. code</i>	<i>data</i>	<i>Freeze</i>	<i>Actuat.</i>			
	ABS		<i>err. code</i>	<i>data</i>	<i>Freeze</i>	<i>Actuat.</i>			
	SRS		<i>err. code</i>	<i>data</i>					
	IMMOBILIZER	<i>info</i>							1.Keys Function(*) 2.Replace IMM Unit (*) 3. Replace ECM/PCM(*) 4. Replace MPCS/MIC U/IMOES(*)

## ELEMENT

From 1999	ENGINE		<i>err. code</i>	<i>data</i>	<i>Freeze</i>	<i>Actuat.</i>			
	AT		<i>err. code</i>	<i>data</i>	<i>Freeze</i>	<i>Actuat.</i>			
	ABS		<i>err. code</i>	<i>data</i>	<i>Freeze</i>	<i>Actuat.</i>			
	SRS		<i>err. code</i>	<i>data</i>					
	IMMOBILIZER	<i>info</i>							1.Keys Function(*)

## ELYSION

	ENGINE		<i>err. code</i>	<i>data</i>	<i>Freeze</i>	<i>Actuat.</i>			
	AT		<i>err. code</i>	<i>data</i>	<i>Freeze</i>	<i>Actuat.</i>			

From 1999	ABS		<i>err. code</i>	<i>data</i>	<i>Freeze</i>	<i>Actuat.</i>		
	SRS		<i>err. code</i>	<i>data</i>				
	OPDS						1.Adjustment(*)	
	BCM		<i>err. code</i>	<i>data</i>		<i>Actuat.</i>	1.Check(*) 2.Adjustment(*)	
	Keyless Access System		<i>err. code</i>	<i>data</i>		<i>Actuat.</i>		1.Keys Function(*) 2.Replace IMM Unit (*) 3. Replace ECM/PCM(*) 4. Replace MPCS/MIC U/IMOES(*)
	IMMOBILIZER	<i>info</i>						1.Keys Function(*) 2.Replace IMM Unit (*) 3. Replace ECM/PCM(*) 4. Replace MPCS/MIC U/IMOES(*)

## FIT

From 1999	ENGINE		<i>err. code</i>	<i>data</i>	<i>Freeze</i>	<i>Actuat.</i>		
	AT		<i>err. code</i>	<i>data</i>	<i>Freeze</i>	<i>Actuat.</i>		
	ABS		<i>err. code</i>	<i>data</i>	<i>Freeze</i>	<i>Actuat.</i>		
	SRS		<i>err. code</i>	<i>data</i>				
	EPS		<i>err. code</i>	<i>data</i>	<i>Freeze</i>	<i>Actuat.</i>		

	IMMOBILIZER	<i>info</i>							1.Keys Function(*) 2.Replace IMM Unit (*) 3. Replace ECM/PCM(*) 4. Replace MPCS/MIC U/IMOES(*)
--	-------------	-------------	--	--	--	--	--	--	--

**FR-V**

From 1999	ENGINE		<i>err. code</i>	<i>data</i>	<i>Freeze</i>	<i>Actuat.</i>			
	AT		<i>err. code</i>	<i>data</i>	<i>Freeze</i>	<i>Actuat.</i>			
	ABS		<i>err. code</i>	<i>data</i>	<i>Freeze</i>	<i>Actuat.</i>			
	SRS		<i>err. code</i>	<i>data</i>					
	EPS		<i>err. code</i>	<i>data</i>	<i>Freeze</i>	<i>Actuat.</i>			
	IMMOBILIZER	<i>info</i>							1.Keys Function(*) 2.Replace IMM Unit (*) 3. Replace ECM/PCM(*) 4. Replace MPCS/MIC U/IMOES(*)

**INSIGHT**

	ENGINE		<i>err. code</i>	<i>data</i>	<i>Freeze</i>	<i>Actuat.</i>			
	AT		<i>err. code</i>	<i>data</i>	<i>Freeze</i>	<i>Actuat.</i>			
	ABS		<i>err. code</i>	<i>data</i>	<i>Freeze</i>	<i>Actuat.</i>			
	SRS		<i>err. code</i>	<i>data</i>					

From 1999	IMMOBILIZER	<i>info</i>							1.Keys Function(*) 2.Replace IMM Unit (*) 3. Replace ECM/PCM(*) 4. Replace MPCS/MIC U/IMOES(*)
-----------	-------------	-------------	--	--	--	--	--	--	--

## INSPIRE

From 1999	ENGINE		<i>err. code</i>	<i>data</i>	<i>Freeze</i>	<i>Actuat.</i>		
	AT		<i>err. code</i>	<i>data</i>	<i>Freeze</i>	<i>Actuat.</i>		
	ABS		<i>err. code</i>	<i>data</i>	<i>Freeze</i>	<i>Actuat.</i>		
	SRS		<i>err. code</i>	<i>data</i>				
	IMMOBILIZER	<i>info</i>						1.Keys Function(*) 2.Replace IMM Unit (*) 3. Replace ECM/PCM(*) 4. Replace MPCS/MIC U/IMOES(*)

## INTEGRA

From 1999	ENGINE		<i>err. code</i>	<i>data</i>	<i>Freeze</i>	<i>Actuat.</i>		
	AT		<i>err. code</i>	<i>data</i>	<i>Freeze</i>	<i>Actuat.</i>		
	ABS		<i>err. code</i>	<i>data</i>	<i>Freeze</i>	<i>Actuat.</i>		
	SRS		<i>err. code</i>	<i>data</i>				

From 1999	IMMOBILIZER	<i>info</i>							1.Keys Function(*) 2.Replace IMM Unit (*) 3. Replace ECM/PCM(*) 4. Replace MPCS/MIC U/IMOES(*)
-----------	-------------	-------------	--	--	--	--	--	--	--

## JAZZ

From 1999	ENGINE		<i>err. code</i>	<i>data</i>	<i>Freeze</i>	<i>Actuat.</i>			
	AT		<i>err. code</i>	<i>data</i>	<i>Freeze</i>	<i>Actuat.</i>			
	ABS		<i>err. code</i>	<i>data</i>	<i>Freeze</i>	<i>Actuat.</i>			
	SRS		<i>err. code</i>	<i>data</i>					
	EPS		<i>err. code</i>	<i>data</i>	<i>Freeze</i>	<i>Actuat.</i>			
	IMMOBILIZER	<i>info</i>							1.Keys Function(*) 2.Replace IMM Unit (*) 3. Replace ECM/PCM(*) 4. Replace MPCS/MIC U/IMOES(*)

## LAGREAT

From 1999	ENGINE		<i>err. code</i>	<i>data</i>	<i>Freeze</i>	<i>Actuat.</i>			
	AT		<i>err. code</i>	<i>data</i>	<i>Freeze</i>	<i>Actuat.</i>			
	ABS		<i>err. code</i>	<i>data</i>	<i>Freeze</i>	<i>Actuat.</i>			
	SRS		<i>err. code</i>	<i>data</i>					
	EPS		<i>err. code</i>	<i>data</i>	<i>Freeze</i>	<i>Actuat.</i>			

	IMMOBILIZER	<i>info</i>							1.Keys Function(*) 2.Replace IMM Unit (*) 3. Replace ECM/PCM(*) 4. Replace MPCS/MIC U/IMOES(*)
--	-------------	-------------	--	--	--	--	--	--	--

**LEGEND**

From 1999	ENGINE		<i>err. code</i>	<i>data</i>	<i>Freeze</i>	<i>Actuat.</i>			
	AT		<i>err. code</i>	<i>data</i>	<i>Freeze</i>	<i>Actuat.</i>			
	ABS		<i>err. code</i>	<i>data</i>	<i>Freeze</i>	<i>Actuat.</i>			
	SRS		<i>err. code</i>	<i>data</i>					
	IMMOBILIZER	<i>info</i>							1.Keys Function(*) 2.Replace IMM Unit (*) 3. Replace ECM/PCM(*) 4. Replace MPCS/MIC U/IMOES(*)

**LIFE**

	ENGINE		<i>err. code</i>	<i>data</i>	<i>Freeze</i>	<i>Actuat.</i>			
	AT		<i>err. code</i>	<i>data</i>	<i>Freeze</i>	<i>Actuat.</i>			
	ABS		<i>err. code</i>	<i>data</i>	<i>Freeze</i>	<i>Actuat.</i>			
	SRS		<i>err. code</i>	<i>data</i>					

From 1999	IMMOBILIZER	<i>info</i>							1.Keys Function(*) 2.Replace IMM Unit (*) 3. Replace ECM/PCM(*) 4. Replace MPCS/MIC U/IMOES(*)
-----------	-------------	-------------	--	--	--	--	--	--	--

## LOGO

From 1999	ENGINE		<i>err. code</i>	<i>data</i>	<i>Freeze</i>	<i>Actuat.</i>		
	AT		<i>err. code</i>	<i>data</i>	<i>Freeze</i>	<i>Actuat.</i>		
	ABS		<i>err. code</i>	<i>data</i>	<i>Freeze</i>	<i>Actuat.</i>		
	SRS		<i>err. code</i>	<i>data</i>				
	IMMOBILIZER	<i>info</i>						1.Keys Function(*) 2.Replace IMM Unit (*) 3. Replace ECM/PCM(*) 4. Replace MPCS/MIC U/IMOES(*)

## MOBILIO

	ENGINE		<i>err. code</i>	<i>data</i>	<i>Freeze</i>	<i>Actuat.</i>		
	AT		<i>err. code</i>	<i>data</i>	<i>Freeze</i>	<i>Actuat.</i>		
	ABS		<i>err. code</i>	<i>data</i>	<i>Freeze</i>	<i>Actuat.</i>		
	SRS		<i>err. code</i>	<i>data</i>				



From 1999	IMMOBILIZER	<i>info</i>							1.Keys Function(*) 2.Replace IMM Unit (*) 3. Replace ECM/PCM(*) 4. Replace MPCS/MIC U/IMOES(*)
-----------	-------------	-------------	--	--	--	--	--	--	--

**MR-V**

	ENGINE		<i>err. code</i>	<i>data</i>	<i>Freeze</i>	<i>Actuat.</i>			
	AT		<i>err. code</i>	<i>data</i>	<i>Freeze</i>	<i>Actuat.</i>			
	ABS		<i>err. code</i>	<i>data</i>	<i>Freeze</i>	<i>Actuat.</i>			
	SRS		<i>err. code</i>	<i>data</i>					

From 1999	IMMOBILIZER	<i>info</i>							1.Keys Function(*) 2.Replace IMM Unit (*) 3. Replace ECM/PCM(*) 4. Replace MPCS/MIC U/IMOES(*)
-----------	-------------	-------------	--	--	--	--	--	--	--

**NSX**

	ENGINE		<i>err. code</i>	<i>data</i>	<i>Freeze</i>	<i>Actuat.</i>			
	AT		<i>err. code</i>	<i>data</i>	<i>Freeze</i>	<i>Actuat.</i>			
	ABS		<i>err. code</i>	<i>data</i>	<i>Freeze</i>	<i>Actuat.</i>			
	SRS		<i>err. code</i>	<i>data</i>					

From 1999	IMMOBILIZER	<i>info</i>							1.Keys Function(*) 2.Replace IMM Unit (*) 3. Replace ECM/PCM(*) 4. Replace MPCS/MIC U/IMOES(*)
-----------	-------------	-------------	--	--	--	--	--	--	--

## ODYSSEY

Up to 2003	ENGINE		<i>err. code</i>	<i>data</i>	<i>Freeze</i>	<i>Actuat.</i>		
	AT		<i>err. code</i>	<i>data</i>	<i>Freeze</i>	<i>Actuat.</i>		
	ABS		<i>err. code</i>	<i>data</i>	<i>Freeze</i>	<i>Actuat.</i>		
	SRS		<i>err. code</i>	<i>data</i>				

From 2004	ENGINE		<i>err. code</i>	<i>data</i>	<i>Freeze</i>	<i>Actuat.</i>		
	AT		<i>err. code</i>	<i>data</i>	<i>Freeze</i>	<i>Actuat.</i>		
	ABS		<i>err. code</i>	<i>data</i>	<i>Freeze</i>	<i>Actuat.</i>		
	SRS		<i>err. code</i>	<i>data</i>				
	OPDS						1.Adjustment(*)	
	BCM		<i>err. code</i>	<i>data</i>		<i>Actuat.</i>	1.Check(*) 2.Adjustment(*)	
	IMMOBILIZER	<i>info</i>						1.Keys Function(*) 2.Replace IMM Unit (*) 3. Replace ECM/PCM(*) 4. Replace MPCS/MIC U/IMOES(*)

## ORTHIA

	ENGINE		<i>err. code</i>	<i>data</i>	<i>Freeze</i>	<i>Actuat.</i>		
--	--------	--	------------------	-------------	---------------	----------------	--	--

From 1999	AT		<i>err. code</i>	<i>data</i>	<i>Freeze</i>	<i>Actuat.</i>		
	ABS		<i>err. code</i>	<i>data</i>	<i>Freeze</i>	<i>Actuat.</i>		
	SRS		<i>err. code</i>	<i>data</i>				
	IMMOBILIZER	<i>info</i>						1.Keys Function(*) 2.Replace IMM Unit (*) 3. Replace ECM/PCM(*) 4. Replace MPCS/MIC U/IMOES(*)

## PARTNER

From 1999	ENGINE		<i>err. code</i>	<i>data</i>	<i>Freeze</i>	<i>Actuat.</i>		
	AT		<i>err. code</i>	<i>data</i>	<i>Freeze</i>	<i>Actuat.</i>		
	ABS		<i>err. code</i>	<i>data</i>	<i>Freeze</i>	<i>Actuat.</i>		
	SRS		<i>err. code</i>	<i>data</i>				
	IMMOBILIZER	<i>info</i>						1.Keys Function(*) 2.Replace IMM Unit (*) 3. Replace ECM/PCM(*) 4. Replace MPCS/MIC U/IMOES(*)

## PILOT

From 1999	ENGINE		<i>err. code</i>	<i>data</i>	<i>Freeze</i>	<i>Actuat.</i>		
	AT		<i>err. code</i>	<i>data</i>	<i>Freeze</i>	<i>Actuat.</i>		
	ABS		<i>err. code</i>	<i>data</i>	<i>Freeze</i>	<i>Actuat.</i>		
	SRS		<i>err. code</i>	<i>data</i>				
	TPMS		<i>err. code</i>	<i>data</i>		<i>Actuat.</i>		

	IMMOBILIZER	<i>info</i>							1.Keys Function(*) 2.Replace IMM Unit (*) 3. Replace ECM/PCM(*) 4. Replace MPCS/MIC U/IMOES(*)
--	-------------	-------------	--	--	--	--	--	--	--

**PRELUDE**

From 1999	ENGINE		<i>err. code</i>	<i>data</i>	<i>Freeze</i>	<i>Actuat.</i>			
	AT		<i>err. code</i>	<i>data</i>	<i>Freeze</i>	<i>Actuat.</i>			
	ABS		<i>err. code</i>	<i>data</i>	<i>Freeze</i>	<i>Actuat.</i>			
	SRS		<i>err. code</i>	<i>data</i>					
	IMMOBILIZER	<i>info</i>							1.Keys Function(*) 2.Replace IMM Unit (*) 3. Replace ECM/PCM(*) 4. Replace MPCS/MIC U/IMOES(*)

**RAFAGA**

	ENGINE		<i>err. code</i>	<i>data</i>	<i>Freeze</i>	<i>Actuat.</i>			
	AT		<i>err. code</i>	<i>data</i>	<i>Freeze</i>	<i>Actuat.</i>			
	ABS		<i>err. code</i>	<i>data</i>	<i>Freeze</i>	<i>Actuat.</i>			
	SRS		<i>err. code</i>	<i>data</i>					

From 1999	IMMOBILIZER	<i>info</i>							1.Keys Function(*) 2.Replace IMM Unit (*) 3. Replace ECM/PCM(*) 4. Replace MPCS/MIC U/IMOES(*)
-----------	-------------	-------------	--	--	--	--	--	--	--

## RIDGELIN E

From 1999	ENGINE		<i>err. code</i>	<i>data</i>	<i>Freeze</i>	<i>Actuat.</i>			
	AT		<i>err. code</i>	<i>data</i>	<i>Freeze</i>	<i>Actuat.</i>			
	ABS		<i>err. code</i>	<i>data</i>	<i>Freeze</i>	<i>Actuat.</i>			
	SRS		<i>err. code</i>	<i>data</i>					
	IMMOBILIZER	<i>info</i>							1.Keys Function(*) 2.Replace IMM Unit (*) 3. Replace ECM/PCM(*) 4. Replace MPCS/MIC U/IMOES(*)

## S-MX

	ENGINE		<i>err. code</i>	<i>data</i>	<i>Freeze</i>	<i>Actuat.</i>			
	AT		<i>err. code</i>	<i>data</i>	<i>Freeze</i>	<i>Actuat.</i>			
	ABS		<i>err. code</i>	<i>data</i>	<i>Freeze</i>	<i>Actuat.</i>			
	SRS		<i>err. code</i>	<i>data</i>					

From 1999	IMMOBILIZER	<i>info</i>							1.Keys Function(*) 2.Replace IMM Unit (*) 3. Replace ECM/PCM(*) 4. Replace MPCS/MIC U/IMOES(*)
-----------	-------------	-------------	--	--	--	--	--	--	--

## S2000

From 1999	ENGINE		<i>err. code</i>	<i>data</i>	<i>Freeze</i>	<i>Actuat.</i>		
	SRS		<i>err. code</i>	<i>data</i>		<i>Actuat.</i>		

## SHUTTLE

From 1999	ENGINE		<i>err. code</i>	<i>data</i>	<i>Freeze</i>	<i>Actuat.</i>		
	AT		<i>err. code</i>	<i>data</i>	<i>Freeze</i>	<i>Actuat.</i>		
	ABS		<i>err. code</i>	<i>data</i>	<i>Freeze</i>	<i>Actuat.</i>		
	SRS		<i>err. code</i>	<i>data</i>				
	IMMOBILIZER	<i>info</i>						1.Keys Function(*) 2.Replace IMM Unit (*) 3. Replace ECM/PCM(*) 4. Replace MPCS/MIC U/IMOES(*)

## SPIKE

From 1999	ENGINE		<i>err. code</i>	<i>data</i>	<i>Freeze</i>	<i>Actuat.</i>		
	AT		<i>err. code</i>	<i>data</i>	<i>Freeze</i>	<i>Actuat.</i>		
	ABS		<i>err. code</i>	<i>data</i>	<i>Freeze</i>	<i>Actuat.</i>		
	SRS		<i>err. code</i>	<i>data</i>				
	EPS		<i>err. code</i>	<i>data</i>		<i>Actuat.</i>		

	IMMOBILIZER	<i>info</i>							1.Keys Function(*) 2.Replace IMM Unit (*) 3. Replace ECM/PCM(*) 4. Replace MPCS/MIC U/IMOES(*)
--	-------------	-------------	--	--	--	--	--	--	--

**STEP WGN**

From 1999	ENGINE		<i>err. code</i>	<i>data</i>	<i>Freeze</i>	<i>Actuat.</i>			
	AT		<i>err. code</i>	<i>data</i>	<i>Freeze</i>	<i>Actuat.</i>			
	ABS		<i>err. code</i>	<i>data</i>	<i>Freeze</i>	<i>Actuat.</i>			
	SRS		<i>err. code</i>	<i>data</i>					
	IMMOBILIZER	<i>info</i>							1.Keys Function(*) 2.Replace IMM Unit (*) 3. Replace ECM/PCM(*) 4. Replace MPCS/MIC U/IMOES(*)

**STREAM**

	ENGINE		<i>err. code</i>	<i>data</i>	<i>Freeze</i>	<i>Actuat.</i>			
	AT		<i>err. code</i>	<i>data</i>	<i>Freeze</i>	<i>Actuat.</i>			
	ABS		<i>err. code</i>	<i>data</i>	<i>Freeze</i>	<i>Actuat.</i>			
	SRS		<i>err. code</i>	<i>data</i>					

From 1999	IMMOBILIZER	<i>info</i>						1.Keys Function(*) 2.Replace IMM Unit (*) 3. Replace ECM/PCM(*) 4. Replace MPCS/MIC U/IMOES(*)
	BCM		<i>err. code</i>	<i>data</i>		<i>Actuat.</i>	1.Check(*) 2.Adjustment(*)	

### TODAY

From 1999	ENGINE		<i>err. code</i>	<i>data</i>	<i>Freeze</i>	<i>Actuat.</i>		
	AT		<i>err. code</i>	<i>data</i>	<i>Freeze</i>	<i>Actuat.</i>		
	ABS		<i>err. code</i>	<i>data</i>	<i>Freeze</i>	<i>Actuat.</i>		
	SRS		<i>err. code</i>	<i>data</i>				

### That's

From 1999	ENGINE		<i>err. code</i>	<i>data</i>	<i>Freeze</i>	<i>Actuat.</i>		
	SRS		<i>err. code</i>	<i>data</i>				
	EPS		<i>err. code</i>	<i>data</i>	<i>Freeze</i>	<i>Actuat.</i>		
	IMMOBILIZER	<i>info</i>						1.Keys Function(*) 2.Replace IMM Unit (*) 3. Replace ECM/PCM(*) 4. Replace MPCS/MIC U/IMOES(*)

### VAMOS

	ENGINE		<i>err. code</i>	<i>data</i>	<i>Freeze</i>	<i>Actuat.</i>		
	AT		<i>err. code</i>	<i>data</i>	<i>Freeze</i>	<i>Actuat.</i>		



From 1999	ABS		<i>err. code</i>	<i>data</i>	<i>Freeze</i>	<i>Actuat.</i>		
	SRS		<i>err. code</i>	<i>data</i>				
	EPS		<i>err. code</i>	<i>data</i>	<i>Freeze</i>	<i>Actuat.</i>		
	IMMOBILIZER	<i>info</i>						1.Keys Function(*) 2.Replace IMM Unit (*) 3. Replace ECM/PCM(*) 4. Replace MPCS/MIC U/IMOES(*)

## Z

From 1999	ENGINE		<i>err. code</i>	<i>data</i>	<i>Freeze</i>	<i>Actuat.</i>		
	SRS		<i>err. code</i>	<i>data</i>				
	EPS		<i>err. code</i>	<i>data</i>	<i>Freeze</i>	<i>Actuat.</i>		

## Zest

From 1999	ENGINE		<i>err. code</i>	<i>data</i>	<i>Freeze</i>	<i>Actuat.</i>		
	AT		<i>err. code</i>	<i>data</i>	<i>Freeze</i>	<i>Actuat.</i>		
	ABS		<i>err. code</i>	<i>data</i>	<i>Freeze</i>	<i>Actuat.</i>		
	SRS		<i>err. code</i>	<i>data</i>				

Created with

 **nitro**<sup>PDF</sup> professional

download the free trial online at [nitropdf.com/professional](https://nitropdf.com/professional)

Created with

 **nitro**<sup>PDF</sup> professional

download the free trial online at [nitropdf.com/professional](https://nitropdf.com/professional)

Created with

 **nitro**<sup>PDF</sup> professional

download the free trial online at [nitropdf.com/professional](https://nitropdf.com/professional)

Created with

 **nitro**<sup>PDF</sup> professional

download the free trial online at [nitropdf.com/professional](https://nitropdf.com/professional)

Created with

 **nitro**<sup>PDF</sup> professional

download the free trial online at [nitropdf.com/professional](https://nitropdf.com/professional)

Created with

 **nitro**<sup>PDF</sup> professional

download the free trial online at [nitropdf.com/professional](https://nitropdf.com/professional)

Created with

 **nitro**<sup>PDF</sup> professional

download the free trial online at [nitropdf.com/professional](https://nitropdf.com/professional)



Created with

 **nitro**<sup>PDF</sup> professional

download the free trial online at [nitropdf.com/professional](https://nitropdf.com/professional)

Created with

 **nitro**<sup>PDF</sup> professional

download the free trial online at [nitropdf.com/professional](https://nitropdf.com/professional)

Created with

 **nitro**<sup>PDF</sup> professional

download the free trial online at [nitropdf.com/professional](https://nitropdf.com/professional)

Created with

 **nitro**<sup>PDF</sup> professional

download the free trial online at [nitropdf.com/professional](https://nitropdf.com/professional)

Created with

 **nitro**<sup>PDF</sup> professional

download the free trial online at [nitropdf.com/professional](https://nitropdf.com/professional)

Created with

 **nitro**<sup>PDF</sup> professional

download the free trial online at [nitropdf.com/professional](https://nitropdf.com/professional)

Created with

 **nitro**<sup>PDF</sup> professional

download the free trial online at [nitropdf.com/professional](https://nitropdf.com/professional)

Created with

 **nitro**<sup>PDF</sup> professional

download the free trial online at [nitropdf.com/professional](https://nitropdf.com/professional)



Created with

 **nitro**<sup>PDF</sup> professional

download the free trial online at [nitropdf.com/professional](https://nitropdf.com/professional)

Created with

 **nitro**<sup>PDF</sup> professional

download the free trial online at [nitropdf.com/professional](https://nitropdf.com/professional)

Created with

 **nitro**<sup>PDF</sup> professional

download the free trial online at [nitropdf.com/professional](https://nitropdf.com/professional)

Created with

 **nitro**<sup>PDF</sup> professional

download the free trial online at [nitropdf.com/professional](https://nitropdf.com/professional)

Created with

 **nitro**<sup>PDF</sup> professional

download the free trial online at [nitropdf.com/professional](https://nitropdf.com/professional)

Created with

 **nitro**<sup>PDF</sup> professional

download the free trial online at [nitropdf.com/professional](https://nitropdf.com/professional)

Created with

 **nitro**<sup>PDF</sup> professional

download the free trial online at [nitropdf.com/professional](https://nitropdf.com/professional)

Created with

 **nitro**<sup>PDF</sup> professional

download the free trial online at [nitropdf.com/professional](https://nitropdf.com/professional)



Created with

 **nitro**<sup>PDF</sup> professional

download the free trial online at [nitropdf.com/professional](https://nitropdf.com/professional)

Created with

 **nitro**<sup>PDF</sup> professional

download the free trial online at [nitropdf.com/professional](https://nitropdf.com/professional)

ACCORD

from - после up to - до