

SUBARU FORESTER

Systems	Sys. Info.	Read-clear Dtc.	Data stream	Actuation	Special functions	Others
Engine Control System	Info	err. Code	data		1.System Running Check Mode 2.Diagnosis Results 3.Dealer Check Mode	
AT	Info	err. Code	data			
Brake Control System	Info	err. Code	data		1.Function check 2.Freeze Frame	
SRS Control System	Info	err. Code	data			
Integ.unit mode	Info	err. Code	data		1.Function Check Sequence 2.Integ.Unit customizing	
Impact Sensor	Info				1.Sensitivity Adjustment Mode	
Air Condition System	Info	err. Code	data			
Air Suspension System	Info	err. Code	data		1.Compulsory Height Control	
Tire pressure monitor	Info	err. Code	data			

SUBARU IMPREZA

Engine Control System	Info	err. Code	data		1.System Running Check Mode 2.Diagnosis Results 3.Dealer Check Mode	
AT	Info	err. Code	data			
Brake Control System	Info	err. Code	data		1.Function check 2.Freeze Frame	
SRS Control System	Info	err. Code	data			
Integ.unit mode	Info	err. Code	data		1.Function Check Sequence 2.Integ.Unit customizing	
Impact Sensor	Info				1.Sensitivity Adjustment Mode	
Air Condition System	Info	err. Code	data			
Air Suspension System	Info	err. Code	data		1.Compulsory Height Control	
Tire pressure monitor	Info	err. Code	data			

SUBARU LEGACY

Engine Control System	Info	err. Code	data		1.System Running Check Mode 2.Diagnosis Results 3.Dealer Check Mode	
AT	Info	err. Code	data			
Brake Control System	Info	err. Code	data		1.Function check 2.Freeze Frame	
Cruise Control System	Info	err. Code	data			
SRS Control System	Info	err. Code	data			
Integ.unit mode	Info	err. Code	data		1.Function Check Sequence 2.Integ.Unit customizing	

Impact Sensor	Info				1.Sensitivity Adjustment Mode	
Air Condition System	Info	err. Code	data			
Air Suspension System	Info	err. Code	data		1.Compulsory Height Control	
Tire pressure monitor	Info	err. Code	data			

SUBARU OUTBACK

Engine Control System	Info	err. Code	data		1.System Running Check Mode 2.Diagnosis Results 3.Dealer Check Mode	
AT	Info	err. Code	data			
Brake Control System	Info	err. Code	data		1.Function check 2.Freeze Frame	
Cruise Control System	Info	err. Code	data			
Integ.unit mode	Info	err. Code	data		1.Function Check Sequence 2.Integ.Unit customizing	
Impact Sensor	Info				1.Sensitivity Adjustment Mode	
Air Condition System	Info	err. Code	data			
Air Suspension System	Info	err. Code	data		1.Compulsory Height Control	
Tire pressure monitor	Info	err. Code	data			

SUBARU R2

Engine Control System	Info	err. Code	data			
AT	Info	err. Code	data			
Brake Control System	Info	err. Code	data			
Electric Power steering	Info	err. Code	data			

SUBARU PLEO

Engine Control System	Info	err. Code	data			
AT	Info	err. Code	data			
Brake Control System	Info	err. Code	data			
Electric Power steering	Info	err. Code	data			

SUBARU VIVIO

Engine Control System	Info	err. Code	data			
-----------------------	------	-----------	------	--	--	--